

— Restoration&Moisture&Ventilation —

# ALORAIR



## SPARE PARTS LIST

### Storm Elite

34	water collect tray		1	RF-DGA125PSJ05
33	pump	component	1	RF-PUMP01A
32	chassis	galvanized sheet	1	RF-DGD125PWJ01
31	wheel Axle bracket	galvanized sheet	2	RF-DGD125PWJ09
30	12 inch wheel	component	2	RF-BZJSJ30
29	compressor bracket		1	RF-DGA160PWJ14
28	compressor	component	1	RF-BZJDQ06
27	low pressure pipe		1	RF-DGA125PXT02
26	high pressure pipe		1	RF-DGA125PXT03
25	Nylon mesh		1	RF-DGA125PSJ04
24	water outlet connector	POM	1	RF-BZJSJ39
23	iron panel	galvanized sheet	3	RF-DGD125PWJ10
22	velcro		2	RF-BZJWJ59
21	handle		1	RF-DGD125PWJ11
20	operating panel sticker		1	RF-DGB125PSJ01
19	operating panel panel	galvanized sheet	1	
18	operating panel	component	1	RF-DGB125PSJ01
17	back housing	LLDPE	1	RF-DGD125PSJ01
16	humidity sensor	component	2	RF-DWA90PDQ05
15	humidity sensor bracket	stainless steel	1	RF-DGB85PWJ13
14	evaporator	component	1	RF-DGA125PXT01
13	electric control cover	galvanized sheet	1	RF-DGD125PWJ08
12	computer board	component	1	
11	electric control box	galvanized sheet	1	
10	wind turbine capacitor	component	1	RF-BZJDQ28
9	exchange cover board	galvanized sheet	1	RF-DGD125PWJ05
8	top support frame	galvanized sheet	1	RF-DGD125PWJ04
7	support frame	galvanized sheet	2	RF-DGD125PWJ02
6	bottom support frame	galvanized sheet	1	RF-DGD125PWJ03
5	front housing	LLDPE	1	RF-DGD125PSJ01
4	air channel	ABS	1	RF-DGA125PSJ06
3	motor	component	1	RF-DGA125PDQ016
2	motor bracket	galvanized sheet	1	RF-DGD125PWJ06
1	air intake grille	ABS	2	RF-DGA125PSJ03
NO	NAME	MATERIAL	QUANTITY	MODEL

