

Restoration&Moisture&Ventilation



SPARE PARTS LIST

Storm Pro

39	coil bracket		1	RF-DGB90PWJ10
38	water outlet connector	POM	1	RF-BZJSJ39
37	air outlet	ABS	1	RF-DGA70PSJ12
36	operating panel	component	1	RF-DGA70PDQ02
35	operating panel bracket	aluminum sheet	1	RF-DGB125PWJ01
34	operating panel bracket sticker		1	RF-DGB125PSJ01
33	back housing	LLDPE	1	RF-DGB90PSJ02
32	electric control box cover	galvanized sheet	1	RF-DGB90PWJ06
31	right exchange bracket	galvanized sheet	1	RF-DGB90PWJ03
30	left exchange bracket	galvanized sheet	1	RF-DGB90PWJ04
29	compressor capacity	component	1	RF-BZJDQ85
28	capacity hook	POM	1	RF-DGA50PSJ02
27	computer board	component	1	RF-DGA70PDQ04
26	electric control box	galvanized sheet	1	RF-DGB90PWJ05
25	rubber foot pad	component	2	RF-BZJSJ44
24	wheel cover	ABS	2	
23	wheel bearing	component	4	RF-BZJWJ11
22	wheel axle	45#	1	RF-DGA70PWJ22
21	12 inch wheel	component	2	RF-BZJSJ30
20	chassis	galvanized sheet	1	RF-DGB90PWJ01
19	compressor	component	1	RF-BZJDQ03
18	high pressure pipe	component	1	RF-DGA90PXT12
17	reversing valve	component	1	RF-DGA90PXT11
16	compressor bracket	stainless steel	1	RF-DGB90PWJ09
15	water collect tray	PP	1	RF-DHM50LSJ02
14	evaporator	component	1	RF-DGA90PXT01
13	volute	galvanized sheet	1	RF-DGB90PWJ11
12	shaft piece	galvanized sheet	1	RF-DWA90PWJ11
11	volute upper cover	galvanized sheet	1	RF-DGA70PWJ12
10	motor	component	1	RF-DGA70PDQ01
9	volute fixing bracket	galvanized sheet	2	RF-DGB90PWJ08
8	exchange cover board	galvanized sheet	1	RF-DGB90PWJ07
7	pump	component	1	RF-PUMP01A
6	humidity sensor	component	1	RF-DWA90PDQ05
5	humidity sensor bracket	stainless steel	1	RF-DGB85PWJ13
4	wind turbine capacitor	component	1	RF-BZJDQ34
3	front housing	LLDPE	1	RF-DGB90PSJ02-1
2	filter	component	1	RF-DGB90PWJ12
1	air intake panel	galvanized sheet	1	RF-DGB90PWJ02
NO	NAME	MATERIAL	QUANTITY	MODEL

